



How to upload a layout package

Firstly you will need to log into your unit using your credentials (the default credentials are remote and 9999) if you have forgotten your credentials please email support (support@onelan.com) for assistance.

From the home screen you will need to go to Layouts>Layout Packages



Once you have done that you will be on the screen shown below



Once you are on this screen if you click choose file, this will then go into the files on your PC, from here choose the layout package that you wish to upload then press upload.

Once this item is uploaded you will then see it appear on the page that you are.

You will then need to click install and this will then install your layout package onto your NTB.